

easyflush direct

installation guide



1 Introduction

The easyflush direct valve provides electronic flushing of the WC without the need for a WC cistern.

There are two versions: easyflush wave is operated by the user bringing their hand towards the infrared sensor. A part flush is triggered by holding the user's hand in place for 1 second; a full flush is triggered by a hand pass of over 1 second. The dual flush setting is a factory default but can be changed by the installer.

easyflush direct walkaway is activated when the user stands up or leaves the cubicle but

it can also be activated by the user bringing their hand toward the sensor. The dual flush setting is a factory default but can be changed by the installer. A part flush is triggered by short user occupancy and a full flush by long user occupancy (over 45 seconds).

With easyflush direct there is no cistern to be refilled; this means a second flush can be activated without a delay. The product includes a hygiene rinse function.

3 YEAR
warranty*

*See page 17 for details



BREEM[®]